



**Veterinary cataract surgery –
we are your experienced partner**

an-vision




an-lens MD8



an-lens MD4



an-lens MD6



an-lens MH9



an-CTR



Instruments



an-lens MD2



alexos3



Sutures



an-blue



Viscoelastics



an-HyPro

an-Instructions

MD8 IOL Loading Instructions




See all our **an-vision** products at:
www.an-vision.com or contact us!

Specifically Designed for Veterinary Use

an-vision GmbH
Neuendorfstr 22a
16761 Hennigsdorf
Germany
T: +49 (0)3302-209 5550
info@an-vision.eu


www.an-vision.com

an-vision Inc.
9067 S.1300 W.
Salt Lake City, UT 84088
USA
T: 801-561-5040
info@an-vision.com




1

Fill the barrel halfway with viscoelastic substance, preferably an-bfh1.8 % or 2.2% or an-visco. Put two lines of visco-elastics to the plane of the cartridge. Do not touch the tip of the cartridge.




2

Pull the lens gently from the lens holder using a forceps with fine rounded tips. Do not let the lens dry up. Do not use the fluid from the bottle for ocular irrigation.




3

Place the lens in the center of the open cartridge. **Note the marked haptic point** to the upper right / lower left with respect to injection direction.



4

Hold optic down, center the IOL on the loading deck of the cartridge. Close the cartridge without clamping the lens.



5

Check the position of the lens within the channel of the closed cartridge. Haptic must not reach up into the closure. Inject some visco into the rear of the cartridge and some into the tip.



6

Injector with loaded cartridge

an-vision